

Normal/Light debris vacuuming (FILTER mode)

Before starting:

- ☐ Check the filter pressure. *If it's at or above 18 psi, BACKWASH + RINSE before vacuuming*
- ☐ Get the vacuum adapter (white hard plastic disk) and black rubber plug from the pool house
- ☐ Inspect the vacuum head and remove debris, if any, from the brushes/wheels underneath
- ☐ Attach the vacuum head + hose to the long pole (if not already together)

Step	Details
1. 'Prime' vacuum hose	Place the vacuum head into the water near the deep end skimmer and pre-fill as much of the hose as possible with water by feeding it hand over hand into the pool down towards the vacuum head.
2. Plug shallow end skimmer	Remove the basket from the shallow end skimmer and place the plug firmly down into the water intake hole at the bottom of the skimmer.
3. Place vacuum adapter + hose into deep end skimmer	Empty the deep end skimmer basket and return it to the skimmer. Press the free end of the vacuum hose onto the adapter plate and place the plate down onto the basket seated in the skimmer. Wait for suction to pull the water from the hose into the skimmer.
4. Vacuum pool, turn pump off when done	Vacuum the pool floor. When vacuuming is complete, turn off the pump using the wall switch.
5. Remove and store vacuum equipment	Remove the vacuum, hose and pole from the water and put them back on the fence. Remove the plug and skimmer adapter and return to the pool house. Empty/replace both skimmer baskets.
6. Turn pump back on	Turn the pump back on using the wall switch and check the pressure. If it has risen to 18 psi or above BACKWASH then RINSE the filter. If not, then don't...you're done!